

The Ultimate Bubble Squeeze Schedule

This is the best schedule that I have found for getting a nice smooth surface when fusing two large pieces of 1/8" glass together. It is long but well worth the time.

Seg	DPH	Temp	Hold
1	300	1050	15
2	120	1250	25
3	300	1370	35
4	300	1450	3-5
5	AFAP	950	35-45
6	200	800	0

Total running time: 9.5 hours. approx.
Dumping heat at 1450 may alter time.

